

<b>Self Serve Programme</b>	
<b><u>First Service 500-800km THEN every 3000km</u></b>	
<b>Braap MOTO3 Motorcycle</b>	COMPLETED
Dealer: PWS Motorcycles Pty Ltd	
LMCT: 12014	
Contact: 0499 27 22 27.	
3/30 Kookaburra St,	
Frankston, 3199	
Phone Number for after sales/ Workshop and Spare Parts and Support	
0449 901 123 Mon-Fri 9-5	
<b>WE RECOMMEND YOU HAVE A container TO PLACE ALL ITEMS IN WHILST WORKING TO ENSURE YOU HAVE NOTHING LEFT OVER WHEN FINISHED</b>	
<b>Oil:</b> 10W/40 Mineral Motorcycle Oil	
Drain oil, check is there any unusual things floating in it.	
Remove Gauze <b>Oil Filter</b>	
Check for any unusual debris	
Clean gauze with Petrol	
Reinstall Oil filter	
Replace oil 1.1 Lt of 10W/40 Mineral <b>motorcycle oil</b> (Castrol 4T)	
<b>Refiit SUMP PLUG</b>	
<b>Air Filter:</b>	
Remove both seats	
Remove cap from air box	
Remove air filter	
Clean with compressed air	
<b>Refit Air filter</b>	
<b>Spark Plug:</b> Remove and Clean	
<b>Idle:</b> Check Idle 1500-2000 Revs	
<b>Horn:</b> Is it working	
<b>Lights:</b> Confirm all lights are working	
Head light low beam	
Head light high beam	
taillight	
indicators	
<b>Chain:</b> Chain health	
Ensure chain is adjusted to recommended tension if not FIX IT	
Lubricate (Do not lubricate it close to the brakes, lubricate from the centre.)	
<b>Tyres: Health</b>	
28 PSI Front	
32 PSI Rear	
Check tyre wear.	
<b>Spark Plug:</b> Remove and Clean	
<b>Swing Arm Bolt:</b> Tension swing arm bolt to 90NM	
Engine Mount Bolts: Check	
Fairing screws: Check	

Bolts: Start from front of bike and work your way back checking ALL bolts.	
Check Neck Nut	
Check fork operation	
Check rear shock operation	
Back wheel: Wobble and Check (wheel bearings?)	
Front wheel: Wobble and Check (wheel bearings?)	
Brakes: visual brakes, are they good	
cable: check clutch cable	
Clutch lever free play	
Throttle lever free play	
I take full responsibility for the Servicing of Motorcycle with Vin Number	
Date	
Name	
Signature	